



Thermakraft corner  
mould stapled to lower  
corners of the opening